

DataLogic Magellan 900i Configuration

July 10, 2026

These instructions are for the Gym Assistant **Premium Desktop Omni Barcode-QR Code Scanner for Check-In.**

To configure your DataLogic scanner for Serial/RS232, scan the three codes below in order:

1. **Start/End** – you will hear one beep
2. **RS-232 Standard** – you will hear three beeps
3. **Label ID Control = Disable** – you will hear three beeps
4. **Start/End** – you will hear one beep, then a pause, then one more beep.

Your scanner is now ready to use!



START / END

You will hear 1 Beep



RS-232 Standard

You will hear 3 beeps



Label ID Control = Disable

You will hear 3 beeps



START / END

You will hear 1 beep, then a pause, then 1 more beep