

# Desktop QR Code Scanner Configuration

---

February 16, 2026



To configure your Desktop QR Code Scanner for Gym Assistant and GateKeeper, scan the QR code for **USB Serial Interface** below. The scanner will emit a single beep followed by 3 more beeps.

The scanner should now show in Device Manager as “USB Serial Device”.

You can also adjust the scanner’s beep volume by scanning one of the volume settings on the next page.

## USB Serial



USB Serial Interface

## Volume Settings

You can adjust the buzzer volume by scanning the following setting code according to the application environment and personal habits.



Mute



Low Volume



Medium Volume



High Volume (default)

## Restore Default Settings

These special QR codes should only be scanned if requested by Gym Assistant Support.



(1) Restore Default SettingsGet Firmware Version



Get Firmware Version